MANOIR MARIE

ARTISANALE VLOEREN

# OUD-GENT 50x50

TECHNICAL DATA
50x50 x 2,8 – 3cm
with joint width of 2 (to 3) mm (as narrow as possible).

This is a new handmade natural product and hence the colour and size of the tiles within 1 batch and between several production batches may differ slightly.




For interior and exterior use.

*This is a new unique handmade product that can only be manufactured in small volumes: please order in time!*

INSTALLING INSTRUCTIONS

- It is of major importance that the tiles are well mixed.
- We recommend to keep a joint width of 2 (to 3) mm. The tiles are handmade, may differ slightly in size and a good installation will require just a little more attention and time.
- To be laid in white mortar bed or a thick glue of 1cm.
- It's appropriate to double-glue the tiles, this means put glue on both the tile and the underground.
- Double-glue the tiles, this means glue both the tile and the underground with glue.
- Joint colour: Silver grey (20L de sable de dune - 10L de sable blanc - 10L de ciment blanc - 1L de gris classique Holcim). In case of doubt, you may ask the floor layer to perform a sample before jointing the whole surface. We advise to apply a less constrasting joint.
- The joint can always be 1 mm deeper than the tiles, so not level with them. This will keep the shape of the tiles visible whereas the joint remains less apparent.
- Before starting the jointing work, moisten the floor. Joint small surfaces at once and sweep them off regularly in order to avoid cement grout film

- Once the tiles are completely dry, rub them in twice with an impregnating agent (Funcosil AG).

**Funcosil AG Instructions:**

**Only apply the impregnating agent when the floor and joints are sufficiently dry (moisture content < 6%).**

1. Shake the bottles well before use.
2. We always use a paint roller with nap and a wide brush.
3. Pour the product into a container (a paint tray is the most practical).
4. Use the brush for the edges, then apply the impregnating product evenly with the roller. Be careful not to apply too much at once to prevent flaking of the product.
5. If only a brush is used, streaks may occur.
6. Apply the impregnating agent both horizontally and vertically. Allow the first coat to dry before applying the second coat.

- Weekly maintenance with a vacuum cleaner, followed by cleaning with a nourishing soap (Lithofin Wash & Clean).
- And now, enjoy the beautiful result!

