MANOIR MARIE

ARTISANALE VLOEREN

HANDICRAFT VENEZIA

TECHNICAL DATA
BANTS 60 FREE LENGTHS x 1.8 to 2cm
With joint thickness 2mm (as close together as possible).
51kg/m² - 23.34m².box 1290kg/box size box 1m40 x 95cm

This is a new handmade natural product and therefore the color and size of the tiles may vary slightly within 1 particular lot and between production lots.



For interior and exterior use.

This is a new unique handmade product that can only be manufactured in small volumes: please order in time!

INSTALLING INSTRUCTIONS

- It is very important that the tiles are nicely mixed.
- The tiles are 60 wide and free, varying lengths, making the tiles always rural
- Sleek look , joints may always cross each other
- We recommend a grout width of 2mm. The tiles are handmade, may vary slightly in size and a good placement therefore requires just a little more attention and time.
- It is best to double glue the tiles, this means coating both the tile and the screed (substrate) with glue.
- To be placed in gray mortar bed or in an adhesive bed of 0.5cm.
- It is best to double glue the tiles, this means to cover both the tile and the screed with glue.
- Joint color: silver grey (20L of dune sand - 10L of white sand -10L of white cement - 1L of Classic gray Holcim). If in doubt, you can have the floor install a sample before grouting the entire surface. We recommend working with a less contrasting grout.
- The grout should always be 1mm deeper than the tiles, not flush with the tiles. This is so that the shape of the tiles is still visible and the grout is less visible.

- Before grouting, wet the floor slightly. Grout small areas at a time and finish off nicely in time, this to avoid a cement slurry.
- Once the tiles are completely dry, rub them in twice with an impregnating agent (Funcosil AG).

Funcosil AG Instructions:

Only apply the impregnating agent when the floor and joints are sufficiently dry (moisture content < 6%).

1. Shake the bottles well before use.
2. We always use a paint roller with nap and a wide brush.
3. Pour the product into a container (a paint tray is the most practical).
4. Use the brush for the edges, then apply the impregnating product evenly with the roller. Be careful not to apply too much at once to prevent flaking of the product.
5. If only a brush is used, streaks may occur.
6. Apply the impregnating agent both horizontally and vertically. Allow the first coat to dry before applying the second coat.

- Weekly maintenance with a vacuum cleaner, followed by cleaning with a nourishing soap (Lithofin Wash & Clean).
- And now, enjoy the beautiful result!

